

TiBe™ Connect

USER GUIDE

Trademarks & Copyrights

© 2013 TICATAG. All rights reserved.
TICATAG, the TICATAG logo, and TiBe are trademarks of TICATAG. All other trademarks included herein are the property of their respective owners.
Bluetooth, Apple, Google, Windows and other trademarks are the property of their respective trademark holders.
TICATAG shall not be liable for technical or editorial errors or omissions contained herein, nor for incidental or consequential damages resulting from furnishing this material. The information is provided « as is » without warranty of any kind and is subject to change without notice. TICATAG also reserves the right to revise the content of this document at any time without prior notice.

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording or storing in a retrieval system, or translated into any language in any form without prior written permission of TICATAG.

Terms & Conditions of Use

TICATAG certifies that its company have declared to the CNIL its geolocation system TiBe - Declaration No. 1836386 - This, in order to avoid other uses than just a statement of positions of the TiBe tracker(s), with a view to provide a better tracking service on a period and send the best alerts for the TiBe owner.

In accordance with the articles 39 and 40 of Law No. 78-17 of 6 Jan. 1978 amended in 2004, referred to as the «Law on Information Technology and Civil Liberties», any person may obtain a report and, if needed, modification or removal of his own information, by writing an email to the management of TICATAG (contact@ticator.com)
You also get the right to object, subject to invoke legitimate reason to be submitted to the agreement of the management of TICATAG.

Informations

TICATAG SAS
4 rue Louis de Broglie - 22300 LANNION
www.ticator.com
support@ticator.com

Specifications



TICATAG © Studio - All Rights Reserved -

What is TiBe ?

Your TiBe is a Bluetooth® Smart device that helps you to easily find your misplaced phone. Other valuables, with a TiBe attached, can be located using your smartphone.

Download the TiBe Application

TiBe runs on the Smartphone Application TiBe.
You can download the TiBe App from the App Store or Google Play.



TIP: Scan this QR-Code to go to the download page of the application.

Prerequisites

TiBe uses the latest Bluetooth low energy technology.

TiBe works with the devices below:

- Apple Smartphones :
IOS8, iPhone 4S, 5, 5C, 5S, 6
- Android Smartphones :
Android 4.3, 4.4 and Bluetooth 4.0 compatible devices

TIP: The Bluetooth 4.0 device list can be found on the Bluetooth website :
<http://www.bluetooth.com/Pages/Bluetooth-Smart-Devices-List.aspx>

Starting your TiBe

TiBe is delivered **Power OFF**
To start the TiBe, press and hold the button on the case top for **FOUR seconds**
One beep 🎵 confirms that TiBe is **Power ON**

Registration

To use the TiBe application **you can register** with your Facebook account or with your email address via the «Sign up» button.



Add TiBe to your Smartphone

To track a TiBe start by associating it to your Smartphone. Select and follow these 3 steps :

1. Press and hold down the button on the case top
2. Wait for validation (see screenshot below)
3. Fill in the description of your TiBe




Note:

- A TiBe can only belong to **one person**.
- If you want to give it to someone else you **must first remove it from your account** (see paragraph Remove your TiBe).
- All **TiBe device versions** are able to be added **to the same account**.

Detach your TiBe from your Smartphone

You can Add / Detach a TiBe from your smartphone at anytime:

1. Select the TiBe you want to detach
2. Select
3. Select « Detach TiBe »



Find your TiBe


The following color coding indicates each TiBe's approximate distance from your smartphone.

- Black : Not in Range
- Blue : Far
- Green : Close
- Red : Very Close

TIP: If you still do not see your TiBe, pressing on the TiBe icon will activate the Buzzer and blinking the light. Release to deactivate the buzzer.

Find your TiBe

By selecting one of your TiBe in the list, you will obtain the following information :



Not in range
Latest location on a map




Replacing the battery

TiBe uses a standard CR2032 coin battery.

Tip : To check the battery power level, choose a TiBe from the list, go to the settings, select

- To replace the battery :
1. Open the TiBe by rotate its top cover anti-clockwise until it stops,
 2. Carefully slide the battery and replace it by the new one, its positive side on the top,
 3. Close the cover back.



TiBe remotes your Internet Of Things

To change TiBe into a connected button :

- 1- Open the TiBe by rotate the cover,
- 2- Replace the bottom part with the one supplied in the package,
- 3- Close the box,



To setting up the TiBe button, go to the settings of the TiBe application and choose the «button» mode.
For more information, go to the FAQ at www.ticator.com or visit www.IFTTT.com

or scan this QRCode to play the video :

Specifications

Battery: CR2032
Temperature range: 14F to 122F
Range emission: 40 m (1575 in)
TiBe is not waterproof
Precautions for use: TiBe contains small parts. Keep out of the reach of children.

